

# PD Dock Upgrade Tool User Guide

---

## Prepare

---

**MUST** connect AC Power, USB-C and HDMI cable



Install Cypress driver at first time.

Name	Date modified	Type	Size
Cypress_Driver	11/7/2018 9:28 AM	File folder	
Setup	11/7/2018 9:28 AM	File folder	
fw_list_v1.6.7_v05.01.03.01	10/30/2018 11:22	Text Document	1 KB
Releasenote	11/6/2018 9:07 PM	Text Document	4 KB
USB-C Dock FW Upgrade Tool	11/7/2018 9:21 AM	Application	10,880 KB

Double click "Cypress\_Driver.bat"

Name	Date modified	Type	Size
Cypress_Driver	9/20/2018 5:31 PM	Windows Batch File	1 KB
CypressDriverInstaller_1	2/4/2016 11:10 PM	Application	21,212 KB
CypressGx3DriverInstaller		Application	6,092 KB

Type: Windows Batch File  
Size: 69 bytes  
Date modified: 9/20/2018 5:31 PM


**( If computer required restart, restart first and continue below upgrade steps. )**

---

## FW Upgrade


---

**Step 1:** Double click "USB-C Dock FW Upgrade Tool.exe"



---

**Step 2:** Read the instruction and click "OK (Button)"




---


**Step 3:** Read the instruction and click "OK (Button)"



**Step 4:** If dock not connect ready, button will be grayed out and show message “Detecting Dock... if wait too long, try re-plug USB-C cable.”




**Step 5:** After dock connected, click “UPGRADE (Button)”




---

**Step 6:** During upgrade process.




---


**Step 7:** Re-plug USB-C cable, wait 3 second and click "OK (Button)" to continue upgrade procedure. (This might not appear every time.)



**Step 8:** Update finished, click "OK (Button)"



**Step 9:** Read output text to confirm upgrade success.




---


## Check Version

---

**Step 1:** After monitor displayed, click "Check Version (Button)"



**Step 2:** Read Version (Product Name and Versions are depends on different FW)





---

**Step 3:** Re-plug USB-C cable, wait 3 second and click "OK (Button)" to continue upgrade procedure. (This might not appear every time.)



---

**Step 4:** Click "Exit (Button)"

